


Phone 952.215.3233 • Fax 877.289.3860 • support@metafarms.com


Assurance Type

Type is the party the audit is being done by. Examples are Internal (1st party), an outside source that is still affiliated with your company (2nd party), or an independent entity (3rd party). These can also be labeled as Auditor, Service Tech and Supervisor depending how you want to set up your company.



Your data entry grid will come up.

To add a new Type, click the Add button. Fill out the grid and click Save. The code must be unique.



To edit a current Type, click the Edit button, make changes and Save.

1 | Page Updated: 12/21/2012